



## Fix the iDrive USB-HDD bootable problem

### Caution

Backup all your data before you are going to do the following steps

1. Make a bootable startup floppy.
  - a. For Win98 & WinMe, select "My Computer->Control Panel->Add/ remove programs->Startup disk->Create disk"
  - b. For WinXP user, right click the "Floppy" icon, select "Format", then check the box next to the item "Create an MSDOS startup disk". Since the MSDOS startup disk do not copy the program **Fdisk** into the floppy, please download it from <http://www.23cc.com/free-fdisk/> and copy it into the floppy
  - c. For Win2000, please download the bootable floppy image from [www.bootdisk.com](http://www.bootdisk.com). And make a bootable floppy.
2. Restart the PC
3. Enter the BIOS menu,
  - a. Disable on-board IDE
  - b. Set the floppy as the first boot device
  - c. Save the CMOS setting and exit
  - d. Reboot
4. Plug the iDrive in the system
5. Insert the bootable floppy
6. Type "Fdisk /mbr" when you are in "A:\>"

\*\*\* FINISH \*\*\*