


Fixing steps for the MP3 Player when no power-on

For Windows 98 / 98SE / ME / 2000 / XP

1. Do **NOT** connect MP3 player to the computer
2. Insert CD ROM driver to install the application for Windows ME / 2000 / XP. After installation procedure, RESTART the computer.
3. Do **NOT** insert any battery, and connect MP3 player to the PC with provided USB cable. Insert new battery after connection.
4. Press “Play” button and hold for 5 seconds to turn on the MP3 player. You will see “READY” on the LCD Display.



5. Click Start → SigmaTel MSCN Audio Player → MSCN Format.



6. Click “Start” button to format the MP3 player. The MP3 player will work properly after finishing all the above steps.