

U-Stik-N USB FLASH Disk

Manual V1.2

Features

U-Stik-N is a portable storage device for desktop and notebook computers. Its security feature allows you to safely store your data. It is also Plug-N-Play compatible with Windows[®] Me; Windows[®] 2000; Windows[®] XP and Windows[®] Vista

- USB Interface and compliant to USB Specification 2.0 and 1.1
- Security Password Protection
- Driverless for Windows[®] Vista, Windows[®] XP, Windows[®] 2000 and Windows[®] Me

System Requirement

1. IBM PC or Compatible, PC or Notebook Computer with Universal Serial Bus port (USB version 1.0 / 1.1 / 2.0)
2. Windows[®] Vista, Windows[®] 2000, Windows[®] Me, Windows[®] 98SE (driver needed)

Driver Installation

There is **U-Stik-N** driver support in Windows[®] Me / Windows[®] 2000 / Windows[®] XP / Windows[®] Vista. After plugging in **U-Stik-N**, Windows[®] will automatically install the driver. Just follow the simple installation procedure, and finally, in "MY COMPUTER" you will find a new icon(s) "REMOVABLE DISK".

Now, you are able to access all features that provided by **U-Stik-N**.



Windows 98 Driver installation

1. Do not plug the **U-Stik-N** in the computer
2. Select "**D:\win98\CB98setup.exe**" where D: is the driver letter of CDROM
3. Plug the **U-Stik-N** in the computer, Windows[®] will detect and install the driver. System reboot is required. After reboot, a removable drive will be shown.

Utilities

Run application "**FlashDiskManager**" by selecting "d:\AP_v1.43\FlashDiskManager.exe", then, click "Setting" button allow you to

- Format the drive
- Make security partition
- Make bootable drive



Note :

1. The max. length of password is 16 characters
2. For making bootable drive, use USB-HDD when the capacity is 1GB or above
3. Some motherboard do not fully compatible with USB-ZIP / USB -HDD bootable device even there is an option in the BIOS setting.

B. Logintool2090.exe



- This application will be in the security partition when you format the drive using security partition option
- Login into security partition







- To exit the security partition, simply safely remove the USB drive.
- The default password is **empty**. Simply click "OK" will login into security partition
- The password can be changed by click "Change" button

Safely remove USB drive from your computer

Close all windows application that are accessing the USB drive. Always make sure no data transfer between USB drive and computer when you disconnect it from your system.

Safely removal USB drive procedures

1. Click the Removable Hardware icon  in the system tray which is in the bottom right corner 
2. It will show the pop-up menu as follows : 
3. Select the "USB mass storage device"
4. After a while, a pop-up message will be shown :



Warning

1. Improper removal USB device, system hangs up, hard reboot and unstable power while data is being written to the USB drive may cause file corruption or permanent damage to the drive. The best way to prevent this is to avoid opening and continuously editing files directly from the USB drive.
2. The USB Drive can be hot unplugged if no write action is performed to it. However, if data has been moved to the USB Disk, then Eject or Safe removal action is needed to prevent the data loss.

Information in this manual is subject to change without notice.